



## ATrack AK11/AK500: JBUS

## 1 ATrack AK11/AK500

- Device must be installed **as high as possible underneath the dashboard** without being obstructed by any metal brackets or framing.

## 2 Female JBUS Port 1

- Plugs into AK11/AK500 JBUS cable's male Plug

## 3 Female JBUS Port 2

- Remove the OEM JBUS port and install this port in OEM port location.

## 4 ATrack AK11/AK500 JBUS Cable

- Plug into second female port of JBUS Splitter Cable.

## 5 Male JBUS Port

- Male port of JBUS Splitter Cable plugs into OEM Female JBUS Port.

