



ATrack AK11/AK500: OBD-II

1 ATrack AK11/AK500

- Device must be installed **as high as possible underneath the dashboard** without being obstructed by any metal brackets or framing.

2 Female OBD-II Port 1

- Plugs into AK11/AK500 OBD-II cable's male Plug

3 Female OBD-II Port 2

- Remove the OEM OBD-II port and install this port in OEM port location.

4 ATrack AK11/AK500 Cable

- Plugs into Female OBD-II Port 1

5 Male OBD-II Port

- Male port of OBD-II Splitter Cable plugs into OEM Female OBD-II port.

