



## ATrack AK11: Hardwired with Temperature Sensor

### 1 ATrack AK11

- Device must be installed **as high as possible underneath the dashboard** without being obstructed by any metal brackets or framing.

### 2 Power Harness

- Connect the **red wire to constant power** source (+)
- Connect the **yellow wire to ignition power** source (+)
- Connect the **black wire to chassis ground** (-)

### 3 Temperature Sensor

- Connect **White Wire** of Temperature Sensor to **Black Wire** of AK11 I/O Harness
- Connect **Red Wire** of Temperature Sensor to **Light Green Wire** of AK11 I/O Harness

