



ATrack AK11: OBD-II with Inputs

1 ATrack AK11

- Device must be installed **as high as possible underneath the dashboard** without being obstructed by any metal brackets or framing.

2 Inputs

- **Dark Green** wire Input 1 (+)
- **Purple** wire Input 2 (-)
- **Blue** wire Input 3 (-)
- **Pink** wire Input 4 (+)

3 AK11 OBD-II Cable

- Plugs into vehicles OEM OBD-II Port

