



ATrack AK11

OBD-II Temperature sensor

ATrack AK11: OBD-II with Temperature Sensor

1 ATrack AK11

- Device must be installed **as high as possible underneath the dashboard** without being obstructed by any metal brackets or framing.

2 Temperature Sensor

- Connect **White Wire** of Temperature Sensor to **Black Wire** of AK11 I/O Harness
- Connect **Red Wire** of Temperature Sensor to **Light Green Wire** of AK11 I/O Harness

3 AK11 OBD-II Cable

- Plugs into vehicles OEM OBD-II Port

