



1 FleetCam 3.0 MDVR

MDVR must be mounted flat and straight with the access door facing front or rear side of the vehicle.

2 Dead-Reckoning GPS Antenna

Antenna must be mounted straight as possible on top of vehicle dashboard, antenna wire must come out of the rear side of the antenna.

3 Power Harness

Red wire to constant power source (+).  
Yellow wire to ignition power source(+).  
Ground wire to chassis ground(-).

4 Extension Cable(s)

Connects to the MDVR AV/IN & IPC ports to the corresponding camera(s).

5 Wi-Fi Antenna

Mount the Wi-Fi antenna as close as possible to the vehicle's Wi-Fi source.

