



1 Tracker

- Plug tracker into Female port of OBD-II Splitter Cable. Tracker must be installed as high as possible underneath the dashboard without being obstructed by any metal brackets or framing.

2 Splitter Cable

- OBD-II Cable allows Tracker to be installed covertly up underneath vehicle's dashboard. Contains 2 Female OBD-II ports & 1 Male OBD-II Port.

3 Male OBD-II Port

- Remove OEM OBD-II Port and install female OBD-II Port of Splitter Cable into the OEM location.

4 Female OBD-II Port

- Male port of OBD-II Splitter Cable plugs into OEM Female OBD-II Port.

