



ATrack AK11

Driver ID Reader

ATrack AK11: Hardwired with Driver ID

1 ATrack AK11

- Device must be installed **as high as possible underneath the dashboard** without being obstructed by any metal brackets or framing.

2 Driver ID Reader

- Connect **Black Wire** of Driver ID Reader to **chassis ground (-)**
- Connect **Gray Wire** of Driver ID Reader to **Light Green Wire** of AK11 I/O Harness

3 Power Harness

- Connect the **red wire** to **constant power source (+)**
- Connect the **yellow wire** to **ignition power source (+)**
- Connect the **black wire** to **chassis ground (-)**

