



ATrack AK11

Door Unlock

## ATrack AK11 with Door Unlock

### 1 ATrack AK11

- Device must be installed **as high as possible underneath the dashboard** without being obstructed by any metal brackets or framing.

### 2 12V Relay

- 85: Connect to **Output Wire (White)** of AK11 I/O Harness
- 86: Connect to **Constant Power Source (+)**
- 87: Connect to **Ground Source (-)**
- 30: Connect to **Door Unlock Ground Trigger (-)**

### 3 Power Harness

- Connect the **red wire** to **constant power source (+)**
- Connect the **yellow wire** to **ignition power source (+)**
- Connect the **black wire** to **chassis ground (-)**

