



Haptic Rumbler

Hardwired

ID/HAPTICRUMBLER/2025/1

1 Power Box

- Install Power Box behind Vehicle Dashboard

2 Hardwire Cable

- **Red Wire:** Constant Power (+)
- **Black Wire:** Ground (-)
- **Yellow Wire:** Connect to **Green Output Wire** of FC Pro Hub or FC Essential Harness

3 Haptic Rumbler Connection

- Connection Point between Haptic Rumbler and Power Box

4 Haptic Rumbler

- Haptic Rumbler must be installed on frame rail support underneath the seat

